3 Easy Steps for Best Driveway Sealing Results

STEP 1: TRIM AND CLEAN SURFACE

a. Sweep entire surface, removing grass cuttings and other debris. Scrape clean all cracks using a screwdriver.

b. Trim grass and bushes away from driveway.

c. Scrub gasoline and oil stains with undiluted Driveway Kleen™ and a wire brush. Shoot stream of water into cracks and flush clean.

d. Wash entire driveway with Driveway Kleen. Then rinse entire driveway surface with clean water.

STEP 2: REPAIR CRACKS AND HOLES

a. Fill cracks up to ½" wide with Crack Filler.

b. For expanding cracks or climates with wide ranges in seasonal temperatures, fill cracks up to ½" wide with Crack Filler.

c. Repair large cracks, deteriorated surfaces,, and small holes up to 1" deep with Patch. Apply with trowel, tapering into existing surface.

d. For holes larger & deeper than 1", use Ready Road Repair Pot Hole Patch. Use tamper to pack material tight into repair. Ready for traffic immediately. Allow to cure a minimum of thirty days prior to seal coating.

PROJECT HOW-TO'S™ COPYRIGHT © 2005 - 2012, GARDNER-GIBSON, INC.